

AIRPORT DIAGRAM

AL-5570 (FAA)

JACKSONVILLE INTL (JAX)
JACKSONVILLE, FLORIDA


ATIS 125.85
JACKSONVILLE TOWER
118.3 317.7
GND CON
121.9 348.6
CLNC DEL
119.5 290.275

81°42'W

81°41'W

30°31'N

JANUARY 2005
ANNUAL RATE OF CHANGE
0.1° W



400 X 200

BAK 14

256.0°

ELEV 26

30°30'N

FIELD
ELEV
29

BAK 14

10000 X 150

SHELTAIR AVIATION
SERVES FBO RAMP

FIRE STATION

CONTROL TOWER
191

SIGNATURE
FLIGHT SUPPORT
FBO RAMP

CITY RAMP

MAIN
TERMINAL

CUSTOMS

AIR CARGO
RAMP 1

AIR CARGO
RAMP 2

AIR CARGO
RAMP 3

30°29'N

SE-3, 19 NOV 2009 to 17 DEC 2009

SE-3, 19 NOV 2009 to 17 DEC 2009

400 X 200

ELEV 27

M1

M2

M3

FLORIDA
ANG
APRON

NWS

7701 X 150

315.9°

ELEV 24

200 X 150

RWY 7-25
S100, D208, ST175, DT358
RWY 13-31
S100, D190, ST175, DT330

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

AIRPORT DIAGRAM

JACKSONVILLE, FLORIDA
JACKSONVILLE INTL (JAX)