


17117

# AIRPORT DIAGRAM

AL-5570 (FAA)

JACKSONVILLE INTL (JAX)  
JACKSONVILLE, FLORIDA


D-ATIS  
125.85  
JACKSONVILLE TOWER  
118.3 317.7  
GND CON  
121.9 348.6  
CLNC DEL  
119.5 290.275



JANUARY 2015  
ANNUAL RATE OF CHANGE  
0.1° W

SE-3, 17 AUG 2017 to 14 SEP 2017

SE-3, 17 AUG 2017 to 14 SEP 2017



RWY 08-26  
PCN 76 R/B/W/T  
S-120, D-250, 2S-485, 2D-350, 2D/2D2-1005

RWY 14-32  
PCN 88 R/C/W/T  
S-120, D-250, 2S-175, 2D-480, 2D/2D2-1000

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.  
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

# AIRPORT DIAGRAM

17117

JACKSONVILLE, FLORIDA  
JACKSONVILLE INTL (JAX)