


17117

AIRPORT DIAGRAM

AL-5570 (FAA)


JACKSONVILLE INTL (JAX)
JACKSONVILLE, FLORIDA

D-ATIS
125.85
JACKSONVILLE TOWER
118.3 317.7
GND CON
121.9 348.6
CLNC DEL
119.5 290.275

VAR 6.2° N

 JANUARY 2015
 ANNUAL RATE OF CHANGE
 0.1° W

SE-3, 13 SEP 2018 to 11 OCT 2018

SE-3, 13 SEP 2018 to 11 OCT 2018



RWY 08-26
PCN 76 R/B/W/T
S-120, D-250, 2S-485, 2D-350, 2D/2D2-1005
 RWY 14-32
PCN 88 R/C/W/T
S-120, D-250, 2S-175, 2D-480, 2D/2D2-1000

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

AIRPORT DIAGRAM

17117

JACKSONVILLE, FLORIDA
JACKSONVILLE INTL (JAX)