
AIRPORT DIAGRAM
14317
HOUSTON/GEORGE BUSH INTERCONTINENTAL/HOUSTON (IAH)
HOUSTON, TEXAS
AIRPORT DIAGRAM
14317
HOUSTON/GEORGE BUSH INTERCONTINENTAL/HOUSTON (IAH)
AL-5461 (FAA)
HOUSTON, TEXAS
ATIS
124.05
HOUSTON TOWER
120.725 (RWY 08L-26R)
125.35 (RWY 08R-26L)
127.3 (RWY 15L-33R, 15R-33L)
135.15 (RWY 09-27)
288.25 (RWYS 15L-33R, 15R-33L)
290.2 (RWYS 08L-26R, 08R-26L, 09-27)
GND CON
118.575 (RWYS 08L-26R, 08R-26L, 09-27)
121.7 (RWYS 15L-33R, 15R-33L)
CLNC DEL
128.1
FIELD ELEV 96
BLAST PAD 400 X 220
086.5°
9000 X 150
266.6°
ELEV 95
ELEV 91
FIRE STATION
NE BRIDGE
FH BRIDGE
ILS HOLD
LAHSO
NK 9402 X 150
ELEV 93
EAST CARGO
ASDE-X Surveillance System in use.
Operate transponders with Mode C on all twys and rwys.
Runway Status Lights in operation.
HANGARS
TERM A
TERM B
TERM C
TERM D
TERM E
EAST BRIDGE
TWR 424 ±
SF BRIDGE
FIRE STATION
CENTRAL CARGO
NORTH RAMP
RA BRIDGE
SC BRIDGE
10000 X 150
ELEV 85
TRANSIENT PARKING
148.6°
1201 X 150
328.6°
ELEV 87
ELEV 86
JANUARY 2010
ANNUAL RATE OF CHANGE
0.1° W
VAR 3.4° E
RWY 08L-26R
PCN 72 R/A/W/T
S-75, D-210, 2S-175, 2D-409, 2D/2D2-873
RWY 08R-26L
PCN 72 R/A/W/T
S-75, D-210, 2S-175, 2D-498, 2D/2D2-873
RWY 09-27
PCN 67 R/A/W/T
D-210, 2S-175, 2D-560
RWY 15L-33R
PCN 72 R/A/W/T
S-100, D-200, 2S-175, 2D-400, 2D/2D2-800
RWY 15R-33L
PCN 94 R/B/W/T
S-75, D-200, 2S-175, 2D-400, 2D/2D2-873
CAUTION: BE ALERT TO RUNWAY CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.
30° 00′ N
29° 59′ N
29° 58′ N
95° 22′ W
95° 21′ W
95° 20′ W
95° 19′ W
95° 18′ W