


APP CRS	Rwy Idg	11236
281°	TDZE	13
	Apt Elev	13

RNAV (GPS) X RWY 28R


SAN FRANCISCO INTL (SFO)

<p>NA</p> <p>Runway 28L and 28R separated by 750 feet centerline to centerline. DME/DME RNP-0.3 NA. When executing a missed approach or go-around, unless otherwise instructed by ATC, initially turn right to 030° utilizing heading mode. Inoperative table does not apply. For uncompensated Baro-VNAV systems, LNAV/VNAV NA below 2°C (36°F) or above 54°C (130°F).</p> <p>*If a go-around executed after passing DARNE, go-around requires a minimum climb of 380 feet per NM to 1800.</p>	<p>ALSIF-2</p> <p> MISSED APPROACH: Climbing right turn to 3000 on heading 030° then direct OAK VOR/DME and hold.</p>
--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------

D-ATIS 113.7 115.8 118.85	NORCAL APP CON 134.5 338.2	SAN FRANCISCO TOWER 120.5 269.1	GND CON 121.8	CINC DEL 118.2	CPDLC
-------------------------------------	--------------------------------------	-------------------------------------------	-------------------------	--------------------------	-------




ELEV 13	D	TDZE 13
---------	----------	---------



TDZ/CL Rwy 19L and 28R
REIL Rwy 1L, 1R, and 10L
HIRL all Rwy

<p>RADAR REQUIRED</p>	
<p>3000</p> <p></p> <p>hdg 030°</p>	<p>VGSI and RNAV glidepath not coincident (VGSI Angle 3.00/TCH 68).</p>



CATEGORY	A	B	C	D
LNAV/VNAV DA*	1140-4	1127	11200-4	